

## **7000 LIQUID SPRAY MASKING**

### **PRODUCT DESCRIPTION:**

7000 Liquid Spray Masking is a fast drying liquid masking material. 7000 prevents primer, paint and various oversprays from sticking on painted surfaces. Our liquid spray masking dries to a tack free film in 20-30 minutes and requires no special equipment to apply. 7000 can be easily rinsed off with water.

### **DIRECTIONS:**

1. Apply one wet coat with a conventional, gravity or HVLP spray gun using a 1.8 - 2.0 fluid tip.
2. Use 35 - 45 psi with gravity gun, 40 - 50 for siphon gun and lower psi can be used with HVLP equipment.
3. After completing the priming, painting and buffing processes, simply wet vehicle, allowing water to stand for 2 - 3 minutes before thoroughly rinsing.
4. 7000 can be baked at 170°F without losing its masking properties.
5. One coat of 7000 should dry in approximately 20 - 30 minutes at 70° F.

### **Caution:**

1. Avoid contact with skin.
2. Use protective equipment when spraying.
3. **DO NOT SET SPRAY MASKED VEHICLE IN DIRECT SUN LIGHT.**
4. **ALLOW CAR TO COOL DOWN AFTER SETTING IN DIRECT SUNLIGHT BEFORE APPLYING SPRAY MASK.**