



CP-8915 FLEXI-GRIP

CP8915 is designed to promote adhesion on all types of plastic parts *except polyethylene*. Works with all types of paints. FLEXI-GRIP will work on bumper covers as well as plastic interior parts. 8915 is easy to use and contains no isocyanates. One aerosol can should treat approximately 7-10 full bumper covers.

Directions:

1. Shake well.
2. Remove all grease, wax and loose dirt.
3. Dry thoroughly.
4. Apply plastic parts cleaner and wipe dry with a clean lint free cloth.
5. Parts can be sanded, however it is not necessary. *Sanding generally further enhances adhesion.*
6. Spray two light wet coats or one medium wet coat of 8915 making sure to avoid runs.
7. Apply primer or paint in 20 – 30 minutes. Final adhesion occurs when paint is thoroughly cured.
8. On flexible parts, be sure and add 9600 UNIVERSAL FLEX ADDITIVE to paint system.